## QUENCHING, SURFACE TREATMENT AND HARDNESS TESTS

Name	Vickers hardness (HV)	Quenching depth (mm)	Strain	Applicable material	Typical materials	Remark	
Through hardening	Max. 750	Full depth	Varies according to material.	High-C steel C>0.45%	SKS3 SKS21 SUJ2 SKH51 SKS93 SK4 S45C	Not applicable to long or precision parts such as spindles, etc.	
Carburizing and quenching	Max. 750	Standard: 0.5 Max. 2	Moderate	Low-C steel C<0.3%	SCM415 SNCM220	<ul> <li>Quenching parts.</li> <li>Quenching depth specified on drawings.</li> <li>Applicable to precision parts.</li> </ul>	
High frequency quenching	Max. 500	1~2	High	Medium-C steel C0.3~0.5%	S45C	<ul> <li>Quenching parts.</li> <li>Expensive in small volume lot.</li> <li>Good strain resistance.</li> </ul>	
Nitriding	900~1000	0.1~0.2	Low	Nitriding steel	SACM645	<ul> <li>Obtains highest hardness of all quenching techniques.</li> <li>Applicable to precision parts.</li> <li>Applicable to spindles for radial bearing.</li> </ul>	
Tuftriding	Carbon steel : 500 SUS : 1000	0.01~0.02	Low	Steel materials	S45C SCM415 SK3 Stainless	<ul> <li>Good fatigue resistance and wear resistance.</li> <li>Same corrosion resistance as zinc plating.</li> <li>Not applicable to precision parts because it can not be polished after heat-treatment.</li> <li>Applicable to dry bearings.</li> </ul>	
Bluing				Wire rod	SWP-B	<ul> <li>Low-temperature annealing.</li> <li>Removes internal stress in forming to enhance elasticity.</li> </ul>	

## Hardness tests and applicable parts

Test method	Principle	Applicable heat-treated parts	Features	Remark
1.Brinell hardness	A (Steel or superhard alloy)     ball indenter is used to indent     the test surface. Hardness is     given as a quotient minus the     surface area of the indent,     computed from the diameter.	<ul><li>Annealed parts</li><li>Normalized parts</li><li>Anchored materials</li></ul>	Applicable to uneven materials and forged products because indent is large.      Not applicable to small or thin specimens.	JISZ2243
2.Rockwell hardness	The standard or test load is applied via a diamond or boll indenter. Hardness is read on a tester.	<ul> <li>Quenched-Tempered parts</li> <li>Carburized surfaces</li> <li>Nitrided surfaces</li> <li>Thin sheets like copper, brass, bronze, etc.</li> </ul>	<ul> <li>① Hardness value obtained quickly.</li> <li>② Applicable as intermediate test to actual products.</li> <li>③ 30 types caution required.</li> </ul>	JISZ2245
3.Shore hardness	The specimen is set on a table. A hammer is dropped from a uniform height. Hardness is based on how high the hammer bounces.	<ul> <li>Quenched-Tempered parts</li> <li>Nitrided parts</li> <li>Large carburized parts, etc.</li> </ul>	1 Extremely easy to operate. Data obtained quickly. 2 Applicable to large parts. 3 Indent is kept shallow, therefore is applicable to actual products. 4 Compact and light-weight. Portable.	JISZ2246
4.Vickers hardness	Uses a diamond 136° square pyramid indenter. Hardness value is obtained as the surface area of the indent, computed from the length of the diagonal lines of the indent.	<ul> <li>Thin parts hardened by high frequency quenching, carburizing, nitriding, electrolytic plating, ceramic coating, etc.</li> <li>Hardened layer depth in carburized and nitrided parts</li> </ul>	1 Applicable to small and thin specimens.     2 Applicable to all materials because of diamond indenter.	JISZ2244